HOMESTEAD FENCE
ARIZONA | OHIO | NATIONWIDE

INSTALLING CONCRETE POST TOWERS

STEP 1: DRILL ANCHOR HOLES *(SEE BELOW)*


PLACE IN LOCATION


MARK HOLE LOCATION

DRILL 3/8" HOLES

STEP 2: ANCHOR TOWER TO FOUNDATION

HAMMER ANCHORS

SET TOWER ON ANCHORS

SECURE WASHERS & NUTS

CONTINUED ON BACK >



DRILL BIT SIZE: **3/8"**
Tamaño de

TIGHTENING TORQUE: **14 ft. lbs.**
Torsión de apriete

MINIMUM ANCHOR EMBEDMENT: **1-1/2"**

The use of a carbide drill bit conforming to ANSI Standard B212.15 is recommended.
Se recomiende el uso de una broca de carburo que conforme a la norma. ANSI B212.15

"How To Install A Post Tower"
Video Link:

https://bit.ly/3NAruJ9

OR

SCAN THIS QR CODE WITH YOUR PHONE TO VIEW

HOMESTEAD FENCE
ARIZONA | OHIO | NATIONWIDE

INSTALLING CONCRETE POST TOWERS

STEP 3: ENSURE TOWER IS SQUARE



WHEN YOU LEVEL YOUR TOWER, YOU MAY FIND YOUR CONCRETE IS UNEVEN. USE WASHERS TO SHIM THE TOWER INTO A VERTICALLY LEVEL POSITION THEN TIGHTEN ANCHOR NUTS TO SECURE THE TOWER.

STEP 4: INSTALL VINYL POST

FINISH INSTALLING FENCE

LIKE OUR PRODUCT?

Please share your valuable comments with more people!

1. **Go to Amazon.com and sign into your account**
2. **Click "Orders"**
3. **Find your "Product" and click "Write a Product Review"**

QUESTIONS OR ISSUES?

If there is anything wrong with your order, PLEASE reach out to us immediately!

Simply go to your order page and send us a message or email us.

support@homesteadvinyl.com